

A XEROX BUILDERS FIELD GUIDE

Building Envelope & Rainscreen Systems

From Weather-Resistive Barriers and Flashing to Drainage Planes and Cladding Attachment

By Mandeep S. — Xerox Builders Ltd.

Licensed Residential Builder, British Columbia
Field Guide Series — Web Edition — August 2026



INTRODUCTION

Why Rainscreen Construction Exists in BC

No cladding is perfectly waterproof. Every siding, stucco, and masonry system will eventually let some water past its outer face — through a hairline crack, a fastener hole, a joint, or simple wind-driven rain. Rainscreen construction starts from that honest assumption instead of pretending it away.

GUIDING PRINCIPLE

A rainscreen wall does not try to keep every drop of water out at the cladding. It assumes some water will get past the cladding, and gives that water a deliberate, drained path back out — before it ever reaches the structure.

British Columbia has particular reason to take this seriously. Coastal BC's wet climate, combined with widespread construction failures in the 1980s and 1990s — commonly referred to as the "leaky condo crisis" — led directly to rainscreen wall assemblies becoming a building code requirement across much of the province, not simply a best practice.

CODE REQUIREMENT

A ventilated or drained rainscreen wall assembly is required by the BC Building Code in most of coastal British Columbia. Confirm the specific requirement, minimum drainage gap, and any exemptions that apply to your climate zone and building type before finalizing a wall design.

This guide covers how a rainscreen wall assembly actually works: the drainage gap, the weather-resistive barrier behind it, the flashing details that protect every opening, and the common mistakes that quietly turn a code-compliant design into a leaking wall.

1 The Building Envelope's Four Control Layers

A building envelope manages four things at once: water, air, heat, and vapour. Each has its own control layer, and a rainscreen wall assembly touches all four — but this guide focuses specifically on the water and drainage side of that system.

- Water control: sheds bulk rain and manages anything that gets past the cladding
- Air control: a continuous air barrier limits uncontrolled air movement through the wall
- Thermal control: continuous insulation limits heat transfer
- Vapour control: manages vapour movement and drying potential

GUIDING PRINCIPLE

These four layers are designed together, not independently. A decision made for drainage — like the depth of a rainscreen gap — can affect how the wall dries, which affects vapour control. Treat the assembly as one system.

2 The Rainscreen Wall Assembly

From interior to exterior, a typical rainscreen wall assembly includes interior finish, framing and insulation, structural sheathing, a weather-resistive barrier (WRB), a drained and vented air gap, and the exterior cladding.




Figure 1 — A rainscreen wall assembly, from interior finish to cladding.

BUILDER'S STANDARD

I treat the drainage gap as a system component with a job to do — not an installation tolerance. If the gap gets compressed, blocked with debris, or skipped in places to save material, it stops doing that job in exactly those places.

3 Types of Rainscreen Systems

Rainscreen assemblies are generally grouped by how much airflow occurs behind the cladding.

REF	System Type	General Description
A.01	Vented / ventilated	Open top and bottom, allows airflow to assist drying
A.02	Drained only	Provides a drainage path but limited airflow
A.03	Pressure-equalized	Designed to reduce the pressure difference driving water inward

DESIGN OPTION

The right system depends on cladding type, wall height, climate exposure and design. A furring-strip gap behind lap siding and a proprietary drainage mat behind stucco are both legitimate rainscreen strategies — they solve the same problem differently.

CODE REQUIREMENT

Minimum drainage gap dimensions are specified in the BC Building Code and may vary by climate zone, exposure, and cladding type. A commonly referenced minimum is in the range of 10 mm, but always confirm the exact figure required for the specific project and jurisdiction.

4 The Weather-Resistive Barrier (WRB)

The WRB — building paper or synthetic house wrap — is the drainage plane behind the rainscreen gap. Its job is to shed any water that reaches it back to the exterior, while still allowing the wall assembly to dry.

BEST PRACTICE

Not all WRB products are interchangeable. Confirm compatibility with the specific cladding, flashing tapes, and sealants being used — some combinations of products are not compatible with each other even though each is acceptable on its own.

The Shingle-Lap Principle


WRB is installed in horizontal courses working from the bottom of the wall upward, with each course lapping over the one below — exactly like roof shingles. This is not a minor installation detail; it is the entire reason the WRB works.

Correct: Shingled Like Roofing



Each course laps OVER the one below — water sheds down and out

Incorrect: Reversed Lap Traps Water



Water collects behind the reversed lap and finds its way inward

Figure 2 — Correct shingle-lap sequence versus a reversed lap that traps water.

GUIDING PRINCIPLE

If the WRB is not lapped correctly, everything installed on top of it — the drainage gap, the cladding, the flashing — is protecting a drainage plane that is already working against itself.

5 Flashing Fundamentals

Flashing directs water at any interruption in the wall — windows, doors, horizontal trim, deck ledgers, and roof-to-wall intersections — back out to the drainage plane rather than into the wall assembly.

GUIDING PRINCIPLE

Every flashing detail follows the same shingle-lap logic as the WRB itself: whatever is higher up the wall must lap over whatever is below it. This single rule governs almost every flashing detail in residential construction.

Common flashing types include head flashing (above openings), sill pan flashing (below openings, sloped to drain), kick-out flashing (where a roof edge meets a

sidewall, directing water away from the wall rather than behind it), and through-wall flashing at horizontal transitions.

6 Window and Door Opening Flashing

Window and door openings are consistently the single most common source of water intrusion in residential construction — far more often from a flashing sequence error than from a failed window unit itself.




Figure 3 — The correct flashing sequence: sill pan first, then jambs, then head flashing last.

The sequence matters as much as the materials: sill pan flashing goes in first and extends past the jambs; jamb flashing is applied next, over the ends of the sill pan; head flashing goes on last, lapping over the top of the jamb flashing and tucking under the WRB above the opening.

BEST PRACTICE

Install the window or door unit's own integral flange according to the manufacturer's instructions in combination with this sequence — manufacturer instructions and correct flashing sequence are not alternatives to each other, they work together.

7 Cladding Attachment and Furring Strips

Where furring strips create the rainscreen gap, they must be fastened back through the WRB and sheathing into structural framing — the cladding's weight, along with wind and seismic loads, ultimately needs to reach the structure.

- | | |
|---|--|
| ☐ Furring strips fastened into framing, not just sheathing | ☐ Gap maintained consistently, not compressed by cladding fasteners |
| ☐ Vertical strips allow drainage; horizontal strips notched or gapped for drainage | ☐ Compatible fastener material for the cladding and furring used |
| ☐ Fastener penetrations through WRB sealed or gasketed where required | ☐ Top and bottom of the gap open or screened, not sealed shut |

BUILDER'S STANDARD

A rainscreen gap that has been accidentally sealed shut at the top or bottom — often by a trim detail added later — stops functioning as a rainscreen. I check both ends of every gap run, not just the field of the wall.

8 Penetrations Through the Wall

Every electrical fixture, hose bib, vent, and mounting bracket that passes through the cladding and WRB is a potential water entry point, and each needs its own flashing or sealant detail appropriate to its location and size.

CODE REQUIREMENT

Penetration sealing and flashing requirements may be specified by the BC Building Code, the WRB manufacturer's installation instructions, or both. Where they differ, confirm which takes precedence for the specific product and jurisdiction.

GUIDING PRINCIPLE

Group penetrations wherever the design allows it. Every additional penetration is another detail that has to be gotten right, forever — fewer penetrations means fewer places for a future failure to start.

9 Foundation-to-Wall Transition

Where the rainscreen wall meets the foundation, the WRB must lap over the foundation waterproofing — not the other way around — so that water draining down the wall continues down and away from the foundation rather than behind it.

BEST PRACTICE

Terminate the drainage gap so water and airflow can exit above grade, and confirm the assembly directs water away from the foundation rather than concentrating it at one point along the wall base.

This transition also needs to accommodate a starter strip or flashing at the base of the cladding, sized to kick water away from the foundation wall rather than letting it run down the face of the foundation.

10 Roof-to-Wall Transition

Where a roof plane meets a sidewall, kick-out flashing directs the roof's water away from the wall rather than allowing it to run down behind the cladding at exactly the point where the roof concentrates the most water.

GUIDING PRINCIPLE

A missing or undersized kick-out flashing is one of the most common causes of concentrated, long-term water damage in residential construction — because it takes roof runoff, which is already collected water, and redirects a large volume of it directly at one small section of wall.

The step flashing along the roof-to-wall intersection must integrate with the WRB using the same shingle-lap logic used everywhere else in the assembly: each piece laps over the one below and behind the one above.

11 Common Rainscreen Mistakes

Most rainscreen failures trace back to a small set of repeated errors:

- ☐ WRB installed with reversed or insufficient laps
- ☐ Drainage gap compressed, blocked, or omitted in places
- ☐ Top or bottom of the drainage gap sealed shut
- ☐ Flashing installed out of sequence (head before sill)
- ☐ Sill pan flashing not extended past the jambs
- ☐ Kick-out flashing missing at roof-to-wall intersections
- ☐ Incompatible WRB, tape, and sealant products used together
- ☐ Penetrations sealed but not properly flashed
- ☐ Furring strips fastened only into sheathing, not framing
- ☐ Foundation transition allows water behind the foundation wall

GUIDING PRINCIPLE

Almost none of these mistakes are visible from outside the finished home. They surface years later, as water damage, mould, or structural decay — by which point the repair is far more invasive than the original correct installation would have been.

12 Pre-Cladding Inspection

Before cladding conceals the WRB, drainage gap, and flashing, this is the last practical opportunity to verify the drainage plane without removing finished exterior work.

- | | |
|---|---|
| ☐ WRB continuous with correct shingle-lap sequence | ☐ Furring strips fastened into framing |
| ☐ All laps and seams sealed or taped per manufacturer instructions | ☐ Foundation-to-wall transition directs water away from foundation |
| ☐ Sill pan flashing installed and extended past jambs | ☐ Penetrations flashed or sealed appropriately |
| ☐ Jamb and head flashing installed in correct sequence | ☐ Photographs taken of all WRB and flashing details |
| ☐ Kick-out flashing installed at all roof-to-wall intersections | ☐ Required inspections completed and documented |
| ☐ Drainage gap consistent and unobstructed | |

13 The Most Important Lessons to Remember

If a homeowner or builder remembers only a few principles from this guide, they should be these:

1. No cladding is perfectly waterproof

Rainscreen design starts from that assumption, not despite it.

2. The drainage gap has a job to do

Do not compress it, block it, or seal its ends shut.

3. Everything laps like shingles

WRB and flashing both follow the same rule: higher laps over lower.

4. Sequence matters as much as materials

Sill, then jambs, then head — in that order, every time.

5. Windows are the most common failure point



Most water intrusion problems start at an opening, not a wall field.

6. Kick-out flashing is not optional

Missing it concentrates roof runoff directly into the wall.

7. Furring strips need to reach framing

The cladding's load has to get to the structure somehow.

8. Product compatibility is not assumed

Confirm WRB, tape, sealant and cladding are compatible together.

9. Almost nothing here is visible once finished

Verify it before the cladding goes on, not after a leak appears.

CLOSING

Conclusion

A rainscreen wall is a quiet system. When it is built correctly, nothing happens — water that gets past the cladding drains away, the wall dries between wetting events, and the structure behind it stays sound for decades. There is no visible reward for getting it right, only the absence of a very expensive problem.

That makes discipline the whole job: lap everything the way water actually flows, sequence flashing correctly at every opening, keep the drainage gap doing its job from top to bottom, and verify it all before the cladding goes on and the wall stops being inspectable.

GUIDING PRINCIPLE

British Columbia learned this lesson at enormous cost. Rainscreen construction is not a design trend — it is the province's answer to a real and expensive history of getting this wrong.

IMPORTANT NOTICE**Please Read Before Using This Guide**

This guide is an educational resource. It does not replace, and must not be treated as a substitute for:

- The current British Columbia Building Code, National Building Code of Canada, or any other applicable code in force at the time of construction.
- Municipal or regional-district bylaws, permit conditions, and inspection requirements.
- Site-specific building envelope design and engineering prepared by a licensed professional.
- Manufacturer installation instructions for any specific WRB, flashing, sealant, or cladding product.
- The professional and legal judgment of building envelope consultants, architects, engineers, and other registered professionals engaged on a specific project.

The technical details, gap dimensions and examples in this guide are general construction information. Actual requirements vary according to climate zone, exposure, cladding type, wall assembly design, manufacturer specifications and project-specific engineering.

Where a conflict exists, the applicable building code, envelope design drawings, manufacturer's installation instructions and qualified professionals take precedence over this guide.

GUIDING PRINCIPLE

This guide reflects the author's own field research, training, and construction experience. It has not yet been reviewed by an independent building envelope consultant or legal professional. Readers must verify every technical statement against the current, authentic codes, standards, and manufacturer instructions applicable to their project before relying on it.

© 2026 Mandeep S. / Xerox Builders Ltd. All rights reserved.

Research and drafting assistance for this guide was provided using AI-based research and writing tools (Claude, by Anthropic), under the direction, technical judgment and final authorship of Mandeep S.

Field Guide Series — Web Edition — xeroxbuilders.ca